



**Kartek.com**  
**951.737.7223**


## SERVO INSTALLATION INSTRUCTIONS

### \*WARRANTY DISCLAIMER\*

BECAUSE OF THEIR INTENDED USAGE, THE MANUFACTURER MAKES NO WARRANTIES WHATSOEVER, EXPRESS OR IMPLIED, ORAL OR WRITTEN TO PURCHASERS OF THEIR PRODUCTS REGARDING PERFORMANCE, SAFETY, FIT, MERCHANTABILITY, OR LENGTH OF SERVICE. PURCHASERS ARE RESPONSIBLE FOR SELECTION OF PROPER GOODS AND MUST RELY ON THEIR OWN SKILL OR JUDGEMENT THAT SUCH GOODS ARE SUITABLE FOR PURCHASERS' APPLICATION.

1. **Caution:** Do not mount the Servo in drivers compartment. A serious injury could occur in the event of a hydraulic line failure.

2. **Important:** You must use a power steering hose meeting SAE 100RS specifications (we recommend our power steering hose kits).



3. Tank must be mounted higher than the pump.

4. Fluid should be 2" inches above the return line. To bleed system, rotate steering wheel lock to lock and hold against stop. Check fluid level after bleeding. Add fluid to proper level if required.

5. Feel free to call us with any questions regarding pump installation or maintaining this system.

**951.737.7223**

**"PARTS NOT INTENDED  
 FOR AIRCRAFT USE"**